


# Quick Start Guide:

## Setting up your GigaMesh





1

Connect GigaMesh to power outlet.



2

When the LED is flashing red, you can pair the GigaMesh with the GigaSpire. Press and hold the WPS buttons on the GigaMesh and then on the GigaSpire for 3 seconds each (less than 30 seconds apart). The LEDs flash green while attempting to pair.



3

Use the solid green LED indicator (displays for 60 seconds at end of pairing cycle) to determine ideal location for the GigaMesh. If necessary, relocate it to a more ideal distance from the GigaSpire and confirm successful pairing after the GigaMesh reboots (repeating steps 2-3 as needed).

GigaMesh location is ideal distance from GigaSpire.



Move GigaMesh closer to GigaSpire.



Move GigaMesh farther away from GigaSpire.



4

If applicable, use the CommandIQ app to set up the GigaSpire. See the CommandIQ Quick Start Guide for guidance.

### Need help?

Contact Technical Support: 1-800-987-2362 or [support@cumberlandconnect.org](mailto:support@cumberlandconnect.org)